

**GENERAL**

1. Read and understand the manual before operating or servicing this machine.
2. Ensure all safety and instruction decals are clean and readable.
3. Check fuel and hydraulic oil levels.
4. Inspect all hydraulic hoses and connections for leaks or damage. DO NOT use hands to find hydraulic leaks.
5. Check bottom tooth bar is clean and free from dust and rock fragments.

**GUIDE GREASING**

6. Raise the top jaw and grease the upper 4 grease zerks.
7. Lower the top jaw and grease the lower 4 grease zerks.
8. Check top tooth bar for any play, adjust the guides as required – refer to manual for instruction.

**TOOTH BAR GREASING**

9. Check that all the teeth extend and retract smoothly, refer to manual for procedure for dealing with sticking or stuck teeth.
10. Check teeth for wear, remove and rotate or