

1. Raise top jaw (Push LEFT lever - FORWARD)

2. Raise table (Push RIGHT lever - FORWARD)

3. Roll rock into cutting position

ENSURE ROCK IS CENTERED WITHIN CUTTER and  
FLATEST SURFACE OF ROCK IS FACE DOWN

4. Lower table (Pull RIGHT lever - to NEUTRAL)  
while steadying rock

5. Bring teeth into contact with rock

(Pull LEFT lever - BACK)

ENSURE TEETH DO NOT COME INTO CONTACT WITH  
THE TOOTH BAR OR THAT ROCK FRAGMENTS DO  
NOT BECOME TRAPPED BETWEEN TOOTH AND  
TOOTH BAR

6. Lock teeth (Pull RIGHT lever - BACK)

7. Cut Rock (Pull LEFT lever - BACK)

8. Keep lower tooth bar clean of all rock dust and  
fragments